



EROAD Clarity™ Dashcam

Quick Start Guide

OPERATING EROAD CLARITY

1. **Start the vehicle.** The dashcam Power LED should light within a minute. If not, call your transport company to report and resolve.

LOGON USERS:


1. If you previously logged on to this EROAD Clarity, you are still logged on until you log off or another driver logs on.
2. Touch your logon fob to the dashcam's 'EROAD' logo until it chimes.
3. To log off, touch your fob to the dashcam again until you hear the chime.

GOOD TO KNOW: EROAD Clarity chimes if the vehicle moves with no driver logged on.

SAVING EVENTS (CONNECTED/SOLO)

Press the button with the red **Record LED** to send a 20-second video clip of an important event to your transport company.

EROAD Clarity chimes to confirm activation. Note that harsh braking, acceleration, and cornering events trigger the dashcam to send a video clip automatically.



WHAT DO YOU HAVE?

EROAD Clarity	Logon	GPS	Rec. Video
Connected	(Ehubo)	✓	✓
Solo	*	✓	✓
Get	*	✓	✓
Locate	*	✓	✗

* *Optional.*

GOOD TO KNOW: A video clip contains the 10 seconds before and the 10 seconds after the manual or automatically-triggered event.

COVER THE LENS IN SECURE AREAS

Cover the front lens with the red lens cap when entering a secure area, and remove it when you exit.



BLUE: Power is on.

GREEN BLINK: Busy - Recording resumes on completion.


RED: Recording video.

RED BLINK: Saving and uploading a clip.

MAINTENANCE

1. If dirty, clean the lenses with a soft cloth.
Never use sprays or fluids.
2. Do not adjust or remove the dashcam or its wiring. Alert your transport company if it needs adjustment, repair, or replacement.

IMPORTANT: EROAD Clarity placement must comply with regulations. Should the dashcam accidentally detach from the windshield, follow your company's policies related to re-mounting.



GOOD TO KNOW: If the cab temperature exceeds 140°F/60°C the dashcam will turn off its LEDs, sound an alert, and temporarily shut down. It should restart after a few minutes, turning the LEDs back on.

RECORDING OPTIONS

EROAD Clarity can be configured by your transport company to:

1. Record video from both cameras, or road-facing only.
2. Optionally record sound inside the cab.
3. Disable the manual trigger. (*Locate*)
4. Disable audio/video recording completely, but still record location, distance traveled and harsh events. (*Locate*)

If enabled, audio/video recording only occurs when ignition is on.

IMPORTANT (Video-enabled Clarity):

EROAD Clarity does not show a live feed of you driving, but an approved reviewer at your company can request a video clip of any time segment. You can also report any time segment to your company within 12 hours of the event so they can manually request and save additional important video clips surrounding it.

GOOD TO KNOW:

Your transport company is required by law to notify you if you are being recorded. Feel free to ask about its policies and related regulations.