





Use this checklist to ensure your drivers are trained on how to properly enable the Texas Intrastate Ruleset on their in-cab device.

To be able to use the Texas Intrastate Ruleset on EROAD's in-cab device, a driver must:


Login to the in-cab device and go to the **Home** screen.




Tap the center of the Home Screen over the counters to access the **Hours of Service** screen.



Tap the **RULESET** tab on the **Hours of Service** screen, 3rd tab to the center right.



The driver will then be able to enable TX Intrastate 70/7 by tapping the circle to the left of the ruleset (**enabled when blue**). If the driver needs to switch back to the USA Property 60/7 or 70/8 ruleset, they would also do that from this screen.



Note: If the Driver cannot see the TX Intrastate 70/7 on their in-cab device as shown above under the **RULESET** tab, it has not been enabled for them first in the back-office DEPOT platform. In DEPOT, tap **Driver** from the red banner, then click on specific driver's name. Their Personal Driver Profile will show up on the right. Under the **Hours of Service** section, tap on the **Permitted Rulesets** for that driver, in this case TX Property 70-hour / 7-day. The driver will now have the TX Intrastate 70/7 as an option on their in-cab device.