

# **EROAD Clarity Dashcams** Connected and Solo

# **Quick Start Guide**

# **OPERATING CLARITY**

- 1. Start the vehicle.
- Both Clarity LEDs should light within a minute. If not, Clarity is not recording. Call your company to report and resolve.


#### **SOLO USERS LOGIN:**

- 1. If you previously logged on to this dashcam, you are still logged on until you log off or another driver logs on.
- 2. To log on, after the LEDs light, touch your logon device to Solo below the 'EROAD' logo until Solo chimes.
- 3. To log off, touch your device to Solo again until you hear the chime.

#### **GOOD TO KNOW:**

Solo alerts you if you move the vehicle with no driver logged on.

Use only the EROAD NFC logon device near Solo. Other NFC items such as credit cards may interfere with the Solo logon function.



## **SAVING EVENTS**

Press the button with the red **Record LED** to send a 20-second video clip of an important event to your transport company. Clarity chimes and the LED blinks to confirm activation. Note that harsh braking, sharp acceleration, and sharp cornering events trigger the dashcam to send a video clip automatically.

## **GOOD TO KNOW:**

A video clip contains the 10 seconds before and the 10 seconds after the manual or automatically triggered event.

# **COVERING THE LENS IN SENSITIVE AREAS**


Remember to cover the front lens with the red lens cap when passing through a sensitive area defined by your company or local regulations. Remove the cap when you exit the area.



#### **MAINTENANCE**

- Clean the Clarity lens when dirty with a soft cloth.
  Never use sprays or fluids.
- 2. Do not adjust or remove your Clarity dashcam or its wiring. Alert your company if Clarity needs adjustment, repair, or replacement.

**IMPORTANT:** Dashcam placement must comply with regulations. If Clarity falls off the windshield, follow your company's policies related to re-mounting.





**GOOD TO KNOW:** The LEDs will turn off and Clarity will temporarily shut down and broadcast an audible alert If the cab temperature ever exceeds 140°F/60°C. Clarity should start again after a few minutes, turning the LEDs back on.

### RECORDING OPTIONS

Clarity records sound inside the cab if it has been set to **Record** mode by your transport company. If enabled, recording only occurs when ignition is on.

Clarity can be configured to record video from both cameras or road-facing only. Ask your company if you have any questions about your configuration.

#### **GOOD TO KNOW:**

Your company is required by law to notify you if you are being recorded. Ask your company about its policies and related regulations.

**IMPORTANT:** Clarity does not show a live feed of you driving but an approved reviewer at your company can request a video clip of any time segment. You can also report any time segment to your company within 12 hours of the event so they can manually request and save additional important video clips surrounding it.

NOTE: Solo dashcam continuously records location, distance traveled, and driver behavior. Please contact your company to discuss.